

**Only one Door per Form**

Date \_\_\_\_\_ Door location \_\_\_\_\_

Customer \_\_\_\_\_

Site \_\_\_\_\_

Contact \_\_\_\_\_



Phone \_\_\_\_\_

Email \_\_\_\_\_

Measured from quote S \_\_\_\_\_

Door width = \_\_\_\_\_

Track length = \_\_\_\_\_

**Plan**

**Elevation**

**Requires 1x M6/M8 or SofStop wheel pack (sold separately)**  
**Standard pack contents:**

- 2x M6 (2 wheel) or M8 (4 wheel) carriages with door stop mounting plate
- Screws to fit mounting plates
- 1x Floor guide
- 2x Track stops


**Door Height Calculation**

Top of track (F.F.L only) \_\_\_\_\_

Less track height (62mm) \_\_\_\_\_

Less clearance above door (15mm suggested) \_\_\_\_\_

Less below door clearance (15mm suggested) \_\_\_\_\_

Door height = \_\_\_\_\_

**Door Width Calculation**

Clear opening \_\_\_\_\_

+ (overlap x 2) \_\_\_\_\_

= Door width \_\_\_\_\_

**Please contact your rep for job progress enquiries or contact our office: 02 9905 0588**

 Email: [estimating@cavitysliders.com.au](mailto:estimating@cavitysliders.com.au)

Signed by CS rep \_\_\_\_\_

Signed by (or on behalf of customer) \_\_\_\_\_

Rep's contact no. \_\_\_\_\_

Print name \_\_\_\_\_

**Only one Door per Form**

Date \_\_\_\_\_ Door location \_\_\_\_\_

Customer \_\_\_\_\_

Site \_\_\_\_\_

Contact \_\_\_\_\_

Phone \_\_\_\_\_


Email \_\_\_\_\_

Measured from quote S \_\_\_\_\_


Door width = \_\_\_\_\_

Track length = \_\_\_\_\_

**Plan**



**Elevation**



**Requires 1x M6/M8 or SofStop wheel pack (sold separately)**

**Standard pack contents:**

- 2x M6 (2 wheel) or M8 (4 wheel) carriages with door stop mounting plate
- Screws to fit mounting plates

- 1x Floor guide

- 2x Track stops



**Door Height Calculation**

Top of track (F.F.L only) \_\_\_\_\_

Less track height (62mm) \_\_\_\_\_

Less clearance above door (15mm suggested) \_\_\_\_\_

Less below door clearance (15mm suggested) \_\_\_\_\_

Door height = \_\_\_\_\_

**Door Width Calculation**

Clear opening \_\_\_\_\_

+ overlap \_\_\_\_\_

Door width = \_\_\_\_\_

**Track Length Calculation**

(DW x 2) \_\_\_\_\_

- overlap \_\_\_\_\_

Track length = \_\_\_\_\_

**Please contact your rep for job progress enquiries or contact our office: 02 9905 0588**

Email: [estimating@cavitysliders.com.au](mailto:estimating@cavitysliders.com.au)

Signed by CS rep \_\_\_\_\_

Signed by (or on behalf of customer) \_\_\_\_\_

Rep's contact no. \_\_\_\_\_

Print name \_\_\_\_\_

**Only one Door per Form**

Date \_\_\_\_\_ Door location \_\_\_\_\_

Customer \_\_\_\_\_

Site \_\_\_\_\_

Contact \_\_\_\_\_

Phone \_\_\_\_\_


Email \_\_\_\_\_

Measured from quote S \_\_\_\_\_


Door width = \_\_\_\_\_

Track length = \_\_\_\_\_

**Plan**



**Elevation**



**Requires 2x M6/M8 or SofStop wheel packs (sold separately)**  
**Standard pack contents:**

- 2x M6 (2 wheel) or M8 (4 wheel) carriages with door stop mounting plate
- Screws to fit mounting plates

- 1x Floor guide

- 2x Track stops



**Door Height Calculation**

Top of track (F.F.L only) \_\_\_\_\_  
 Less track height (62mm) \_\_\_\_\_  
 Less clearance above door (15mm suggested) \_\_\_\_\_  
 Less below door clearance (15mm suggested) \_\_\_\_\_  
 Door height = \_\_\_\_\_

**Door Width Calculation**

Clear opening + (overlap x 2) \_\_\_\_\_  
 ÷ 2 \_\_\_\_\_  
 Door width = \_\_\_\_\_

**Track Length Calculation**

(DW x 4) \_\_\_\_\_  
 - (2 x overlap) \_\_\_\_\_  
 Track length = \_\_\_\_\_

**Please contact your rep for job progress enquiries or contact our office: 02 9905 0588**

**Email: [estimating@cavitysliders.com.au](mailto:estimating@cavitysliders.com.au)**

Signed by CS rep \_\_\_\_\_

Signed by (or on behalf of customer) \_\_\_\_\_

Rep's contact no. \_\_\_\_\_

Print name \_\_\_\_\_